

## VIAIR® SAE Conversion Kit Installation Instructions

**Note:** Wire stripper/crimping tool recommended

**Step 1:** Cut the compressor cord approximately 2 inches behind the alligator clamps.

**Step 2:** Strip the cable tips leaving approximately ¼ inch of wire exposed.

**Step 3:** Insert the stripped wires into the butt connectors, and crimp.

**Step 4:** Repeat step 3 to connect the 2-Pin SAE wires to the compressor, making sure the red (power) wire connects to the compressor wire containing a fuse holder

**WARNING: Rated for 12V up to 30 Amp Max (360 watts)**

