



88P PORTABLE COMPRESSOR SPORT COMPACT SERIES

PART NO. 00088



IMPORTANT:

It is essential that you and any other operator of this product read and understand the contents of this manual before installing and using this product.

SAVE THIS MANUAL FOR FUTURE REFERENCE

USER MANUAL



88P PORTABLE COMPRESSOR

Please read this instruction manual carefully prior to operating this product. Pay particular attention to the **CAUTION** and **WARNING** statements in this manual. Failure to comply with these instructions could result in personal injury or property damage. Retain these instructions for future reference.

DESCRIPTION:

This portable oil-less air compressor is designed to operate by attaching the heavy duty battery clamps to your vehicle's battery while the engine is on. It can be used for inflating tires, sports balls, or topping off pressure for single person tube rafts, air mats, and other uses.

IMPORTANT SAFETY INSTRUCTIONS:

CAUTION: The compressor has been designed to provide long-term, trouble-free operation. To reduce risk of electrical shock or electrocution and to prevent damage to your compressor, follow these simple guidelines:

1. Do not disassemble. Do not attempt to repair or modify this unit.
2. Never allow children to operate this compressor. Close supervision is necessary when this compressor is being used near children.
3. This compressor will become very hot during and immediately after use.
4. Do not touch any part of this compressor with bare hands, other than the ON/OFF switch and carry handle, during or immediately after use.
5. Provide sufficient cooling time before storing the unit.
6. Never operate the compressor near fire, flammable gas or liquid.
7. This is an oil-less compressor. No lubrication is required.
8. Do not pump anything other than atmospheric air.
9. Never use this product while sleepy or drowsy.
10. Be sure the unit's power switch is in the OFF position when not in use.
11. Use only in well ventilated areas.
12. The unit should be used only in dry environment. Protect the unit from rain, snow or other sources of moisture.
13. Never carry the air compressor by the hose or power cord.
14. Never point air nozzle towards another person or any part of the body.
15. Inflate items only to their manufacturer's recommended pressure.
16. Do not leave air compressor running unattended. It could burst tires or other items.

88P PORTABLE COMPRESSOR

FEATURES:

1. Built-In 120 PSI Pressure Gauge*
2. LED Work Light/Power Indicator
3. Dual Battery Clamps with 20-amp Inline Fuse Holder
4. Deluxe Carry Bag with Bright Orange Lining for Enhanced Visibility
5. 3-Pc. Inflation Tips Kit
6. Presta Valve Adaptor
7. Oil-Less Design
8. Gearless Direct-Drive Motor
9. Permanently Lubricated Bearings
10. Compact Size for Easy Carrying and Storage
11. Solid Brass Twist-On Tire Chuck
12. Power Cord: 10 ft. / Air Hose: 16 ft.

OPERATING INSTRUCTIONS:

IMPORTANT: Engine MUST be running while using this compressor.

Before attaching air compressor's power cord to power source, check to make sure that the ON/OFF switch of your compressor is in the **OFF** position.

CAUTION: Your Portable Air Compressor is Moisture and Dust Resistant, but **NOT WATER OR DUST PROOF**. Never place compressor in soft sand while running the compressor. Vibration from the compressor will cause the compressor to settle into soft sand, resulting in compressor drawing in foreign particles. Never expose compressor to water while running the compressor.

TIRE INFLATION:

1. This compressor is designed to operate on 12 volts DC.
2. To obtain power, connect battery clamps to positive and negative terminals of battery.
3. Turn your vehicle engine on.
4. Attach the twist-on air chuck to the tire's valve stem.
5. Turn the compressor power switch to ON and begin to inflate tire.
6. When the pressure gauge indicates the desired pressure, switch the unit OFF and remove the air hose from the tire's valve stem.
7. To check and verify the actual tire pressure the compressor must be in OFF position.

Please Note: During inflation, due to air velocity, pressure gauge cannot provide accurate pressure readings, to check and verify the actual tire pressure the compressor must be in OFF position.

CAUTION: To avoid over inflation, never exceed recommended pressure. Doing so may cause articles to burst and can cause serious bodily injury. Always make sure the Portable Compressor's power cord is uncoiled and fully extended when using your air compressor to avoid overheating the power cord.

FOR ALL OTHER INFLATABLE OBJECTS, INCLUDING BICYCLE TIRES, TOYS, AND SPORTS BALLS:

IMPORTANT: Engine MUST be running while using this compressor.

1. A selection of inflation tips is provided to fit some inflatable objects. Simply screw the appropriate nozzle into the tip of the air hose.
2. Attach the appropriate nozzle to article to be inflated and turn the power switch to the ON position.
3. When article is inflated to desired firmness, turn the compressor off. Do not over inflate.

88P PORTABLE COMPRESSOR

MAINTENANCE INSTRUCTIONS:

Turn **OFF** and unplug Air Compressor. Your air compressor is equipped with permanently lubricated, maintenance-free motor. Never try to lubricate the compressor. Use only mild soap and a cloth dampened with hot water to clean plastic parts. Avoid any type of detergents or solvents, which might contain chemicals that could damage plastic portions or painted surfaces of the compressor. All other services should be performed by a qualified technician.

MODEL 88P SPECIFICATIONS:

Part Number:	00088 / 88P
Weight:	4.75 lbs. / 2.15 kg.
Voltage:	12V DC
Max. Amp Draw:	20 amps
Max. Working Pressure:	120 PSI*
Max. Duty Cycle (@ 72°F):	25 Min. @ 30 PSI
Flow Rate @ 0 PSI (13.8 Volts):	1.47 CFM
Dimensions:	9.8" (L) x 3.2" (W) x 5.6" (H)
Ambient Temperature:	-4°F ~ 158°F

* Do not exceed compressor's max working pressure to prevent damage to the compressor.

LIMITED WARRANTY:

VIAIR Corporation warrants this product, when properly installed and under normal conditions of use, to be free from defects in workmanship and materials for a period of one year from its original date of purchase. To receive warranty service or repair, please contact VIAIR Corporation.

Returns should be made within one year of the date of purchase, after a Return Goods Authorization (RGA) number has been assigned by VIAIR Corporation. To obtain RGA, fax a copy of your receipt to (949) 585-0188. For complete warranty details, please visit: www.viaircorp.com/warranty

PLEASE NOTE:

THIS WARRANTY COVERS PRODUCT DEFECTS ONLY; IT DOES NOT COVER INCIDENTAL OR CONSEQUENTIAL DAMAGES AS RESULT OF MISUSE OR ABUSE.

This Manual is proprietary to VIAIR Corporation and no ownership rights are hereby transferred. No part of the Manual shall be used, reproduced, translated, converted, adapted, stored in a retrieval system, communicated or transmitted by any means, for any commercial purpose, including without limitation, sale, resale, license, rental or lease, without the prior express written consent of VIAIR. VIAIR does not make any representations, warranties or guarantees, express or implied, as to the accuracy or completeness of the Manual. Users must be aware that updates and amendments will be made from time to time to the Manual. It is the user's responsibility to determine whether there have been any such updates or amendments. Neither VIAIR nor any of its directors, officers, employees or agents shall be liable in contract, tort or in any other manner whatsoever to any person for any loss, damage, injury, liability, cost or expense of any nature, including without limitation incidental, special, direct or consequential damages arising out of or in connection with the use of the Manual.

All third party product names, logos, and brands are property of their respective owners. All company, product service and trademark names are for identification purposes only. Use of these names, logos, and brands does not imply ownership or endorsement.



15 EDELMAN • IRVINE, CA 92618
TEL: (949) 585-0011 • FAX: (949) 585-0188
www.viaircorp.com